



PROCESSES:

1. SAW CUT SHOULDER - DEPTH OF 1/2" TO 1"
2. IF NEEDED, REMOVE ANY DETERIORATED CONCRETE
3. PRIME EXISTING CONCRETE SURFACES
4. FILL LEVEL WITH EPOXY JOINT FILLER
5. INSTALL NEW FLOORING PER SPEC
6. RE-ESTABLISH JOINT VIA SAW CUT THROUGH EPOXY JOINT FILL AND NEWLY INSTALLED FLOORING
7. INSTALL BACKER ROD
8. FILL JOINT WITH URETHANE JOINT FILLER